


AutoCAD 2000





Setting For Print

- Before doing any drawing, please type “limits” under command (at the bottom left corner) and then press the ENTER button.
- Set the coordinates for bottom left corner to (0,-457)
- Set the coordinates for top right corner to (609,0)
- Complete the drawing under the working area





- Choose the “Print” icon
- Select Printer “ILS- ”
- Click “Properties” button



Choose “Custom Properties” and click Custom Properties at bottom

Setting laser parameter and others under ILS driver

- Choose any sample under Plot Device (Ex. acad.ctb)
- Choose “Edit”



- Choose all colors in Plot Device
- Set the line type to solid
- Set the line width to 0.0000mm
- Save & Close

- Under Plot Scale, set the scale to 1:1
- Chose Extents
- Click ok

